

## Floor Care Guidelines for Marmoleum® Click with Topshield2™

Forbo Marmoleum® Click with Topshield2™ is a natural product made primarily from renewable resources, including linseed oil, wood flour, and pine rosins. Click's inherent anti-static properties repel dust and dirt, which reduces exposure to allergens and makes it easier to clean, thus contributing to improved indoor air quality.

Marmoleum® Click features Topshield2™ which is an occupancy-ready, factory applied finish. This means that at the time of installation, cleaning with a neutral pH cleaning solution is all that is necessary. Lots of floors and finishes work well in theory, but only Marmoleum® Click with Topshield2™ works well in the real world, where staining agents do not get removed in time, dirt and grit does not get cleaned up regularly, and your non-renewable finish gets permanent stains and scratches. Topshield2™ has been designed to create a Marmoleum® that meets the demands of every day use and is even more resistant to dirt pick-up, less prone to wear and has improved resistance to scratches and stains, and thus creating a floor that demonstrates a lasting performance over time. Unlike PUR finishes that will show wear and dirt concentration encapsulated in micro scratches over time, Marmoleum® Click with Topshield2™ can be refreshed and renewed, generating a new finish, turning Marmoleum® Click into what is probably the best performing resilient floor in the real world.

### **INITIAL CLEANING**

For new installations exposed to normal construction soil and traffic.

1. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
2. Mix a neutral pH cleaning solution according to the label directions.  
**IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this document for recommended products.**
3. Apply the solution to the floor. Do NOT flood the floor. The solution can be applied with either a mop and bucket or an automatic scrubber.
4. Scrub the floor with a rotary scrubber or automatic scrubber using a 3M™ Red Buffer Pad #5100 or equivalent.
5. If not using an automatic scrubber, pick up the scrubbing solution with a wet vacuum (preferred) or a squeegee and a mop.
6. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with wet vacuum or automatic scrubber.
7. Allow the floor to dry thoroughly before allowing traffic.

### **ROUTINE CLEANING**

Cleaning performed a minimum of once a day, depending on the application, type of traffic and hours of operation.

1. Stains or spills should be wiped or mopped up immediately with a damp mop using a neutral pH cleaning solution. Rinse the affected area with clean, cool water. Be sure to allow the floor to dry thoroughly before allowing traffic.  
**IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this document for recommended products.**
2. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
3. Mix a neutral pH cleaning solution according to the label directions.  
**IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this document for recommended products.**
4. Apply the solution to the floor. Do NOT flood the floor. The solution can be applied with either a mop and bucket or an automatic scrubber with a 3M™ Red Buffer Pad #5100 or equivalent.
5. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with wet vacuum or automatic scrubber.
6. Allow the floor to dry thoroughly before allowing traffic.

## Floor Care Guidelines for Marmoleum® Click with Topshield2™

---

### **INTERIM CLEANING**

As needed, depending on the application, type of traffic and hours of operation.

1. Remove all surface soil, debris, sand and grit by sweeping, vacuuming or dust mopping.
2. Mix a neutral pH cleaning solution according to the label directions.  
**IMPORTANT: The pH of the cleaner in solution must be between 6 – 8 pH. Please refer to the list at the end of this document for recommended products.**
3. Apply the solution to the floor. Do NOT flood the floor. The solution should be applied with either a mop and bucket or an automatic scrubber.
4. Scrub the floor with a rotary scrubber or automatic scrubber using a 3M™ Red Buffer Pad #5100 or equivalent for light soiling, a 3M™ TopLine Autoscrubber Pad #5000 or equivalent for medium soiling or a 3M™ Blue Cleaner Pad #5300 or equivalent for heavy soiling.
5. If not using an automatic scrubber, pick up the scrubbing solution with a wet vacuum (preferred) or a squeegee and a mop.
6. Rinse the entire floor surface with a clean mop using clean, cool water. Pick up rinse water with wet vacuum or automatic scrubber.
7. Allow the floor to dry thoroughly before allowing traffic.
8. If desired, one of the following procedures can be performed:
  - a. Spray buff the floor using a 175 RPM swing machine and a 3M™ Red Buffer Pad #5100 or equivalent, followed by dust mopping.
  - b. Apply a mop-on restorer and burnish using a 3M™ Top Line Speed Burnish Pad #3200 or equivalent, followed by dust mopping.
  - c. Burnish / Dry Buff the floor using a 3M™ Eraser Pad #3600 or equivalent, followed by dust mopping.
9. If the floor requires restoration cleaning procedures, contact Forbo Technical Services.

### **NOTE:**

Weather, traffic, and geographical location will influence the required frequency of this procedure. For example, in areas where there are large amounts of snow and chemicals used in the winter months it will likely be necessary to perform this procedure more frequently. In dry climates, or where there is less dirt traffic, it may not be necessary to perform this procedure as frequently.

### **CAUTION:**

Marmoleum® Click with Topshield2™ can be damaged by traditional wet stripping methods. If the above floor care recommendations are followed, no wet stripping will be necessary. If wet stripping methods are or have been used on the floor, contact Forbo Technical Services for additional information.

Forbo Marmoleum® Click with Topshield2™ should NEVER be subjected to traditional, aggressive wet stripping. These floors should be cared for by a staff trained to understand the following:

- Forbo Marmoleum® Click with Topshield2™ is OCCUPANCY READY following installation.
- Removal of Topshield2™ is NOT recommended.
- A regular floor care program, as described above, should be followed closely. Contact Forbo Technical Services with any additional questions.

## Floor Care Guidelines for Marmoleum® Click with Topshield2™

---

### **RECOMMENDED FLOOR CARE PRODUCTS**

#### **Neutral pH Cleaners:**

Forbo Neutral pH Cleaner  
ProLink Level 7  
Spartan Damp Mop  
3M Neutral Cleaner 3H  
Diversey Stride

#### **Spray Buffs:**

Forbo Spray Buff  
ProLink Enhance  
Spartan Spray Buff  
3M Top Line Pre-Burnish Conditioner  
Diversey Snapback

#### **Mop on Restorers:**

Forbo Mop on Restorer  
ProLink Optimum Response  
Spartan SunSwept  
3M Top Line Pre-Burnish Conditioner  
Diversey Snapback UHS

### **For additional information on a product or for your local supplier, contact:**

Forbo Flooring Systems  
+800 842 7839  
[www.forboflooringNA.com](http://www.forboflooringNA.com)

ProLink  
+800 745 4657  
[www.prolinkhq.com](http://www.prolinkhq.com)

Spartan  
+800 537 8990  
[www.spartanchemical.com](http://www.spartanchemical.com)

3M  
+800 852 9722  
[www.3m.com/building](http://www.3m.com/building)

Diversey  
+800 558 2332  
[www.diversey.com](http://www.diversey.com)

Forbo's Floor Care Guide contains additional information about floor care and is available for download at [www.forboflooringna.com](http://www.forboflooringna.com). For a hard copy, or for additional information on Topshield2™, contact Forbo Technical Services at +800 842 7839.